



# PLEASE READ BEFORE USE

CARTRIDGE SHOULD BE KEPT AT 70°F+ FOR BEST RESULTS

**450 ML Cartridge**  
Dispensing Gun:  
Newborn 435-XSP


**900 ML Cartridge**  
Dispensing Gun:  
Albion B26-T900 ML

or similar 26:1 thrust ratio dispensing gun


## INSTRUCTIONS FOR USING CARTRIDGE UNIT

**1**

SHAKE WELL BEFORE USE




Unscrew Locking Nut and Remove D Caps




**2**

Place Static Mixer Over Cartridge Neck and Secure Tightly with Locking Nut





**3**

Pull Back Pistons in Gun and Securely Load Cartridge in Cradle



**4**


Hold Gun Straight Up at a 90° Angle and Slowly Pull Trigger to Purge Air from Unit. Drive Material to Top of Mixer.



**5**


Tilt Gun Down and Squeeze First 2-3 Shots of Material into A Disposable Cup, Etc.

Gun Should Be Tilted Down Whenever Dispensing or When Cartridge is Being Used.



**6**

To Re-use Cartridge, Tilt Cartridge Unit Down, Remove Mixer, Wipe Excess Material Off Cartridge Neck, Then Replace D-Caps and Screw on Lock Nut. Use New Mixer with Next Application.



UPDATED 05/20


**DEFECT PREPARATION IS CRITICAL!**

Spal-Pro 2000 can be used to permanently repair a variety of common floor defects, but proper defect preparation is critical in ensuring that your repair will last. There are two important factors in repairing any floor defect:


REPAIR AREA MUST BE DRY AND COMPLETELY CLEAN  
OUTSIDE OF REPAIR AREA SHOULD HAVE A VERTICAL EDGE...  
DO NOT FEATHEREDGE REPAIRS!

Edges of repair can be defined using a concrete saw or right angle grinder with a diamond/abrasive blade. A cold chisel is also acceptable. Vertical edge of repair area should be 1/2" minimum or 3/4"+ (preferred). Any concrete that is not structurally sound should be removed along with any debris, dirt, oils, etc.


**Spalled Joints**



**Random Cracks**



**Gouges, Holes**




**INSTRUCTIONS FOR FILLING FLOOR DEFECTS**

**1 Defects Less than 2" Wide**

For Narrower Joints, Cracks, Popouts, etc., Prepare Area as Outlined in Defect Preparation and Slightly Overfill Defect With Material.

**2**

Allow Material to Cure into a Solid and Razor off Flush with Floor Surface Using Tile Scraper with Disposable Blade.



**1 Defects 2" or Wider**

For Wider Joints, Cracks, Pot Holes, Etc., Prepare Area as Outlined in Defect Preparation. Efforts Should Be Made to Fill Defect Flush as Shaving is Very Difficult for Wide Areas. If Material is Overfilled Slightly, It Can Be Sanded Down Using a Sanding Block or Sander at Low Speed.

Joints and Cracks Should Be Monitored To Ensure Material Does Not Sink and Leave a Concave Profile. Apply Additional Material if Necessary.

